

Vehicles


- [How to edit a vehicle's information?](#)
- [How to add a vehicle to a group?](#)
- [What is Driver Authentication?](#)
- [How to assign a key to a vehicle?](#)
- [How to immobilise a vehicle from the vehicles page?](#)

How to edit a vehicle's information?

The screenshot displays the TRAK'N GO web application interface. On the left, a sidebar menu lists various sections: Dashboard, Assets, Vehicles, Geofences, Alerts, Groups, User Management, Reports, and Account. The 'Vehicles' section is highlighted, and a yellow circle with the number '1' points to it. The main content area shows a table of vehicles with columns for Icon, Registration, and Name. Two vehicles are listed: 'Car - DEMO-EX1 - South Austr...' (Demo 1) and 'Car - DEMO-EX2 - South Austr...' (Demo 2). A yellow circle with the number '2' points to the pencil icon in the 'Actions' column of the first vehicle. An 'Edit Vehicle' modal is open in the center, containing a form with fields for Type (Car), Name (Demo 1), Registration Number (DEMO-EX1), Registration State (South Australia), Make (Hilux), Model (Toyota), Year (2020), Color (White), Current Odometer (0), and Last Serviced (0). A yellow circle with the number '3' points to the form fields. At the bottom of the modal, a 'SAVE' button is highlighted with a yellow circle and the number '4'. The background interface also shows tabs for Keys, Geofences, Alerts, Groups, and Actions, with a 'RENAME KEYS' button in the top right.

1. Make sure you are on Vehicles page.
2. Click the pencil button on the vehicle that you want to edit.
3. Make the desired changes.
4. Click SAVE to make the changes.


How to add a vehicle to a group?



1. Make sure you are on the vehicles page.
2. Click on the indicated button for the vehicle that you want to add to a group.
3. Select the groups that you want the vehicle to appear in.
4. Click ASSIGN to make the changes.


What is Driver Authentication?

How to assign a key to a vehicle?



1. Make sure you are on the vehicles page.
2. Click the key icon for the vehicle that you want.
3. Select the keys that you want to assign to the vehicle.
4. Click ASSIGN to make the changes.

How to immobilise a vehicle from the vehicles page?



1. Make sure you are on the Vehicles page.
2. Click the car icon for the vehicle that you want to immobilise/mobilise.
3. Select from immobilise or mobilise.
4. Click CONFIRM to send the command to the tracker.