


# How to assign vehicles to a geofence?



1. Make sure you are on the Geofence page.
2. Select a geofence from the drop down list to open it.
3. Click ADD TO GEOFENCE button. This will bring up the dialog box.
4. Check the vehicles that you want to assign to this geofence.
5. Click NEXT to move onto the next page.
6. Click the + button to add a timeslot.
7. Configure the timeslot. From left to right you can:  
Name the timeslot, Select whether to notify you instantly or in a daily email, on entry or on exit, the start and end time for each day, days of the week and finally you click the red bin to remove the timeslot.
8. Click FINISH to save the changes.

Dashboard

Assets

Vehicles

Geofences

Alerts

Groups

User Management

Reports

Account

How-to Videos

REPORT

LOGOUT

Geofence

Select a Geofence

Para Vista Geofence

ADD TO GEOFENCE

GROUP ASSIGNMENT

REMOVE

Para Vista Geofence

Search Vehicle

Enabled

Type

Name

Registration

Actions

No Vehicles Assigned

Rows per page: 10

0-0 of 0

1

Select Vehicles to be included

2

Assign Timeslots to the Vehicles

Name	Instant	Enter/Exit	Start Time	End Time	Days	Actions
Weekday 24/7	<input type="checkbox"/>	<div>Entry</div> <div>Exit</div>	00:00	23:59	<div>Mon</div> <div>Tue</div> <div>Wed</div> <div>Thu</div> <div>Fri</div> <div>Sat</div> <div>Sun</div>	<div></div>
<div>+</div>						

CANCEL

BACK

FINISH

7

8

6

Revision #4

Created 5 August 2022 05:42:45 by Jatin Kumar

Updated 12 August 2022 02:13:32 by Jatin Kumar