

What are alerts?

There are seven alerts in Trakngo.

Speed alert: This will alert you if a vehicle goes above a set speed.

Service alert: This will alert you if a vehicle needs to be serviced.

Temperature alert*: This will alert you if the temperature of a vehicle between goes outside of a set range. Note: this requires a temperature probe to be installed in your vehicle.

Tamper alert*: This will alert you if the tracker was unplugged from your vehicle.

Stolen alert: This will alert you of any activity on a vehicle. It cannot tell you whether your vehicle is being stolen. Only assign vehicles that you know to be stolen.

Towing alert: This will alert you if a vehicle is being towed.

Offline alert: This will alert you if a vehicle was offline for more than a set number of hours.

* : Appropriate tracker and/or accessory required.

Revision #3

Created 5 August 2022 05:43:05 by Jatin Kumar

Updated 8 December 2023 05:19:08 by Jatin Kumar