Vehicles

- How to edit a vehicle's information?
- How to add a vehilce to a group?
- What is Driver Authentication?
- How to assign a key to a vehicle?
- How to immobilise a vehicle from the vehicles page?

How to edit a vehicle's information?



1. Make sure you are on Vehicles page.
2. Click the pencil button on the vehicle that you want to edit.
3. Make the desired changes.
4. Click SAVE to make the changes.

How to add a vehilce to a group?



1. Make sure you are on the vehicles page.
2. Click on the indicated button for the vehicle that you want to add to a group.
3. Select the groups that you want the vehicle to appear in.
4. Click ASSIGN to make the changes.

What is Driver Authentication?

How to assign a key to a vehicle?



1. Make sure you are on the vehicles page.
2. Click the key icon for the vehicle that you want.
3. Select the keys that you want to assign to the vehicle.
4. Click ASSIGN to make the changes.

How to immobilise a vehicle from the vehicles page?



1. Make sure you are on the Vehicles page.
2. Click the car icon for the vehicle that you want to immmobilise/mobilise.
3. Select from immobilise or mobilise.
4. Click CONFIRM to send the command to the tracker.